Eclypse STB

Eclypse STB Setup

1. Press STB one time. The STB button at the top of the remote should flash once.
2. Hold the Setup button until the STB button blinks twice.
   a. Press 982. If the STB button blinks twice that means the remote is locked. If the STB button blinks 4 times that means the remote is Unlocked.
   b. Make sure the remote is Unlocked.
3. Press the STB button once.
4. Hold Setup until the STB button blinks twice.
5. If you have the ADB set top box enter the code 2586. If you have the Amino set top box press 1481.
6. The STB button should blink twice.
7. Verify the correct code has been entered by aiming the remote at the set top box and changing channels, and bringing up the guide.
8. After verification, press the STB button one time.
9. Hold Setup button until the STB button blinks twice.
10. Press 982. The STB button should blink twice to indicate that it is locked.

Setting the TV Code

1. Press and HOLD the SETUP until the Mode Key blinks twice
2. Press and release TV button at the top of the Remote Control
3. Find your TV Code in the table below
4. Press and hold that 1 digit key.
5. Let go of the key as soon as your TV cuts off.
6. If the TV doesn't cut off try Steps 1-5 again with the next code.
7. If none of the codes work press SETUP until the TV key blinks twice, then press the TV button.
8. Press and hold the OK/Select Key.
9. Then let go of the OK/Select when your TV turns off.

DIGIT	1	2	3	4	5	6	7	8	9	0
TV	Insignia Dynex	LG / Zenith	Mitsubishi	Panasonic	Phillips / Magnavox	Samsung	Sharp	Sony	Toshiba	Vizio